

AQUARIUS

PerfectFit® Shutter Lite Troubleshooting


Spares

If there is a need to replace faulty, missing or damaged components, the following items are available to order as spares.

Caps


To remove the caps, use a small flat-head screwdriver or putty knife to carefully pry them off, taking care not to damage the surrounding area. Then, gently press the new cap into place.

Stile cap



Code	Description
57159	P.Fit Shutter Stile Cap Cotton White
57168	P.Fit Shutter Stile Cap Arctic White

Tilt rod end cap



Code	Description
57160	P.Fit Shutter Tilt Bar Cap Cotton White
57169	P.Fit Shutter Tilt Bar Cap Arctic White

Screw Cover cap




Code	Description
57157	P.fit shutter rail screw/tension cap Cotton White
57166	P.fit shutter rail screw/tension cap Arctic White

Brackets


See fitting guide for replacement / install of bracket.

Note: Brackets are only available in White.



Code	Description
57175	P.Fit Shutter Fixing Bracket 18mm
57176	P.Fit Shutter Fixing Bracket 20mm
57177	P.Fit Shutter Fixing Bracket 22mm
57178	P.Fit Shutter Fixing Bracket 24mm
57179	P.Fit Shutter Fixing Bracket 26mm
57180	P.Fit Shutter Fixing Bracket 28mm
57181	P.Fit Shutter Fixing Bracket 30mm

Tilt bar cuff link




Code	Description
57161	P.Fit Shutter Tilt Bar Cuff Link Cotton White
57170	P.Fit Shutter Tilt Bar Cuff Link Arctic White

To replace the tilt bar cuff links, follow these steps:

1. Pull the damaged cuff link towards you to release it from the louvre.



2. Once released, twist the cuff link counter clockwise and pull it down to remove it from the tilt rod.



3. Take the new cuff link and insert the pin into the hole in the tilt rod.



4. Turn the cuff link clockwise to lock it in place. Ensure that the cuff link is facing the correct direction.





5. Align the cuff link with the louvre and apply a small amount of pressure to reconnect to the louvre.



6. Verify that the cuff link is securely attached and functioning properly before use.

Handle Rebates



Code	Description
57183	P.Fit Shutter RH/ LH Stile Rebate Handle Cotton White
57084	Pfit Shutter Bottom rebate Arctic White
57194	P.Fit Shutter Stile Rebate Handle Cover Cotton White
57182	Pfit Shutter Bottom rebate Arctic White

To replace the rebate, simply pull the damaged or faulty rebate off the rail, and then slide the new one into place.